



Hanging Chandelier Disassembly Instructions

Place your hanging chandelier cake on a flat smooth surface to work with.

To disassemble your Cake Stackers set first unscrew your hanging bolt that is sticking out of the top cake tier and set aside or in the box for the return of pieces. Gently slide your cake serving knife underneath the pre-cut cake board of the top tier. Lift the cake using the cake board and place on a smooth surface (this is also where you will cut your cake).

Unscrew the center post by hand, set aside in your box. Slide the support plate off and set aside.

You should now be looking at the top of your next cake tier.

Repeat the process until all pieces are taken apart and all cake is removed.

For more help please visit our website and click our videos tab
www.cakestackers.com

Or call us at
(772) 617-0129