



Upside Down Disassembly Instructions

To disassemble your Cake Stackers set first gently slide your cake serving knife underneath the pre-cut cake board of the top largest tier. Lift the cake using the cake board and place on a smooth surface (this is also where you will cut your cake).

Unscrew the center post by hand, set aside in your box for parts. Slide the support plate off and set aside.

You should now be looking at the top of your next cake tier.

Repeat until all pieces are taken apart and all cake is removed.

For more help please visit our website and click our videos tab

www.cakestackers.com

Or call us at
(772) 617-0129